

Operator: JSS/AMB/JESS Vessel: VNA Area
 Process: Thermal Mapping Product: With Load
 Session Start: 2007-04-04 22:00:00 Time Zone: Taipei Standard Time (UTC offset 08:00:00)
 Session Stop: 2007-04-10 16:30:00
 Session Name: C:\Documents and Settings\er\Documents\Applications\Warehouse\Warehouse Validation.d7x
 Session Text: Thermal Mapping VNA_AREA



Validation Solutions

Statistics

Name: Statistics Report
 Description: Warehouse Validation
 Type: Temperature
 Start Time: 2007-04-04 22:00:00
 Stop Time: 2007-04-09 22:00:00
 Global Min.: 19,0 °C 2007-04-08 04:00:00 LC 25
 Global Max.: 23,2 °C 2007-04-09 15:30:00 LC 7
 2007-04-09 16:00:00 LC 7
 Global Average: 20,7 °C
 Min average: 20,0 °C LC 28
 Max average: 21,8 °C LC 7
 Global Delta: 4,2 °C
 Global Standard Deviation: 0,7 °C

| ID | Name | Description | Min. | Max. | Average | Delta | Standard Deviation |
|-------|-------|-------------|---------|---------|---------|--------|--------------------|
| 90172 | LC 1 | Temperature | 20,0 °C | 21,5 °C | 20,9 °C | 1,5 °C | 0,4 °C |
| 90143 | LC 2 | Temperature | 20,4 °C | 22,9 °C | 21,5 °C | 2,5 °C | 0,7 °C |
| 90161 | LC 3 | Temperature | 19,8 °C | 21,5 °C | 20,7 °C | 1,7 °C | 0,4 °C |
| 90145 | LC 4 | Temperature | 20,0 °C | 23,0 °C | 21,4 °C | 3,0 °C | 0,8 °C |
| 90136 | LC 5 | Temperature | 20,2 °C | 22,9 °C | 21,5 °C | 2,7 °C | 0,7 °C |
| 90141 | LC 6 | Temperature | 19,7 °C | 21,2 °C | 20,4 °C | 1,5 °C | 0,3 °C |
| 90155 | LC 7 | Temperature | 20,5 °C | 23,2 °C | 21,8 °C | 2,7 °C | 0,7 °C |
| 90133 | LC 8 | Temperature | 19,5 °C | 21,0 °C | 20,4 °C | 1,5 °C | 0,4 °C |
| 90171 | LC 9 | Temperature | 19,6 °C | 21,6 °C | 20,7 °C | 2,0 °C | 0,5 °C |
| 90181 | LC 10 | Temperature | 19,8 °C | 21,1 °C | 20,6 °C | 1,3 °C | 0,3 °C |
| 90152 | LC 11 | Temperature | 19,9 °C | 22,6 °C | 21,1 °C | 2,7 °C | 0,7 °C |
| 90169 | LC 12 | Temperature | 20,0 °C | 21,9 °C | 20,9 °C | 1,9 °C | 0,5 °C |
| 90129 | LC 13 | Temperature | 19,5 °C | 21,0 °C | 20,3 °C | 1,5 °C | 0,3 °C |
| 90116 | LC 14 | Temperature | 19,7 °C | 21,2 °C | 20,3 °C | 1,5 °C | 0,3 °C |
| 90182 | LC 15 | Temperature | 19,6 °C | 21,1 °C | 20,3 °C | 1,5 °C | 0,3 °C |
| 90178 | LC 16 | Temperature | 19,4 °C | 20,9 °C | 20,2 °C | 1,5 °C | 0,4 °C |
| 90160 | LC 17 | Temperature | 20,4 °C | 23,0 °C | 21,6 °C | 2,6 °C | 0,7 °C |
| 90167 | LC 18 | Temperature | 19,4 °C | 21,0 °C | 20,2 °C | 1,6 °C | 0,3 °C |
| 90170 | LC 19 | Temperature | 19,4 °C | 21,1 °C | 20,2 °C | 1,7 °C | 0,4 °C |
| 90168 | LC 20 | Temperature | 19,8 °C | 21,5 °C | 20,6 °C | 1,7 °C | 0,4 °C |
| 90153 | LC 21 | Temperature | 20,1 °C | 22,6 °C | 21,4 °C | 2,5 °C | 0,7 °C |
| 90127 | LC 22 | Temperature | 20,3 °C | 22,8 °C | 21,5 °C | 2,5 °C | 0,7 °C |
| 90148 | LC 23 | Temperature | 19,6 °C | 21,5 °C | 20,6 °C | 1,9 °C | 0,5 °C |
| 90173 | LC 24 | Temperature | 19,3 °C | 21,3 °C | 20,2 °C | 2,0 °C | 0,4 °C |
| 90137 | LC 25 | Temperature | 19,0 °C | 20,9 °C | 20,0 °C | 1,9 °C | 0,4 °C |
| 90164 | LC 26 | Temperature | 19,2 °C | 21,1 °C | 20,1 °C | 1,9 °C | 0,4 °C |
| 90156 | LC 27 | Temperature | 19,9 °C | 21,4 °C | 20,8 °C | 1,5 °C | 0,4 °C |
| 90154 | LC 28 | Temperature | 19,1 °C | 20,8 °C | 20,0 °C | 1,7 °C | 0,3 °C |
| 90147 | LC 29 | Temperature | 20,0 °C | 21,9 °C | 21,0 °C | 1,9 °C | 0,5 °C |
| 90165 | LC 30 | Temperature | 19,5 °C | 21,0 °C | 20,3 °C | 1,5 °C | 0,3 °C |

Operator/Date: