

Operator: Validation Manager Vessel: Warehouse
Process: Validation Product: Pharma
Session Start: 22-11-2013 09:14:03 Time Zone: UTC offset 01:00:00
Session Stop: 22-11-2013 09:14:12
Session Name: Cold Store Validation
Session Text:



Statistics

Name: Statistics

Description:

Input parameters

Data Series Type: Temperature
Data series: LA 03, LA 02, LC 01
Start Time: 25-11-2013 16:52:40
Stop Time: 26-11-2013 08:02:10
Output: Data Series analysis
Functions: Min., Max., Average, Delta

Data Series analysis

Min average 4,28 °C LA 03
Max average 4,45 °C LA 02

ID	Name	Min.	Max.	Average	Delta
138509	LA 03	3,72 °C	5,11 °C	4,28 °C	1,39 °C
141932-2	LA 02	3,84 °C	5,26 °C	4,45 °C	1,42 °C
141932-1	LC 01	3,37 °C	5,35 °C	4,32 °C	1,98 °C