

Operator: Validation Manager Vessel: Tunnel  
 Process: Validation Product: Food  
 Session Start: 22-11-2013 09:29:08 Time Zone: UTC offset 01:00:00  
 Session Stop: 22-11-2013 09:29:19  
 Session Name: Pasteurisation Validation  
 Session Text:



## Statistics

Name: Statistics

Description:

## Input parameters

Data Series Type: Temperature  
 Data series: P1, A1, P3, P2, A2  
 Start Time: 05-03-2009 12:49:52.029  
 Stop Time: 05-03-2009 13:30:07.678  
 Output: Data Series analysis  
 Functions: Min., Max., Average, Delta

## Data Series analysis

Min average 48,19 °C P3  
 Max average 50,46 °C A1

ID	Name	Min.	Max.	Average	Delta
11538-1	P1	26,54 °C	62,11 °C	50,15 °C	35,57 °C
11538-2	A1	27,74 °C	62,91 °C	50,46 °C	35,17 °C
14319	P3	27,21 °C	61,96 °C	48,19 °C	34,75 °C
888888-1	P2	26,84 °C	62,11 °C	50,40 °C	35,27 °C
888888-2	A2	28,79 °C	62,85 °C	50,27 °C	34,06 °C