

RL4106 transmitter

Pro RL4000RH/T Series

Part of the **Hanwell Pro** RL4000RHT Series, the RL4106 combines temperature and humidity measurement using an integral Sensiron SHT35 sensor. The Unit includes an LCD display and utlises the 434.075MHz frequency as standard.

Features

- ✓ Combined temperature & humidity measurement
- \checkmark LCD display with 50,000 data readings per channel & up to 2 years battery life
- √ Superior performance hardware & high accuracy sensors
- √ Easily accessible battery & USB socket
- √ Low power radio for long distance transmission (3km over open ground)
- √ Complies with RoHS, EU & WEEE directives
- √ Carries UKCA and CE Marking

Typical Applications

- Dry storage
- · Ambient room conditions

Always ask for a long-range signal strength test.



We can prove ours to be unrivalled.

Instrumentation specification		
Dimension	110 x 80 x 35mm (Excl. ancillaries)	
Weight	200 grams	
Power supply	1 x 3.6V AA Lithium battery	
Case material	ABS & PC	
Memory capacity	50,000 readings per channel (unit will wrap when full)	
Clock accuracy (logging)	20 ppm at 25°C	
IP Rating	IP30	
System Temperature Accuracy (Transmitter Unit + Sensor) Sensiron SHT35 Probe		
Temperature accuracy	+/- 0.3°C at -20°C to +60°C	
Long term drift	<0.03°C/yr	
System Humidity Accuracy (Transmitter Unit + Sensor) Sensiron SHT35 Probe		
Humidity accuracy	+/- 3%RH at +25°C	
Humidity range	0 - 100% RH	
Long-term drift	<0.25% RH/yr	
Transmitter Unit		
Measuring range	Temp: -20°C to +60°C RH: 0-100% non-condensing	
Operating range	-20°C to +60°C in a non-condensing RH environment	
Storage temperature	-40°C to +60°C	









Product code: RL4106-434.075

Radio transmitter functions	
Frequency options	A range of frequencies are available between 433-458MHz. Country specific regulations apply.
Radio power	10mW
Radio range	3km over open ground
Battery life	Up to 2 years (dependent on conditions of use and instrument settings)
Software required	W900 – Standard EMS Software Package W906 – Validated EMS Software Package *See EMS datasheet for further options
Software compatibility	EMS - All Versions
Hardware required	CR2 / CR3 – Controller SR2 – Smart Receiver REP – Repeater

Accessories	
Y119	Wall mounting bracket
88706	AA Lithium battery

Manufactured by Ellab Monitoring Solutions











Resolution

Temp: 0.1°C RH: 0.1%